


HOW TO USE THE COOK TOP




A quick guide to making sure you know how to use the Cook Top correctly.




SEASON BEFORE USE ! FOLLOW SEASON GUIDE

①




ENSURE THE BUSH TELLY IS SET UP ON A LEVEL SURFACE

②



USE THE THE HANDLE TO PICK UP THE COOKTOP FROM THE BACK

③



PLACE THE HOT PLATE ON TOP ON THE BUSH TELLY, INTO THE GIVEN SLOTS.



THE BUSH TELLY WILL BE **HOT YOU MUST WEAR FIRE RATED GLOVES**



HIGHLY RECOMMENDED BE **BEHIND THE BUSH TELLY WHEN COOKING**