

# COOK TOP SEASONING GUIDE

- 1. Clean the Cooktop:** Before seasoning, wash the Cooktop thoroughly with warm soapy water to remove any manufacturing residue. Rinse well and dry completely.
- 2. Apply a Thin Coat:** Using a clean cloth, apply a thin, even coat of Bush Telly Care Wax to the entire Cooktop. Wipe away any excess until only a light film remains.
- 3. Heat the Cooktop:** For the best seasoning results, place the Cooktop in a household oven at 250°C for 45–60 minutes. Alternatively, season it on your Bush Telly over a medium fire until the surface begins to lightly smoke.
- 4. Repeat 2–4 Times:** Allow the Cooktop to cool naturally, then repeat the seasoning process 2–4 times before your first cook to build a durable, natural non-stick surface.
- 5. Maintain the Seasoning:** After each use, clean and dry the Cooktop thoroughly. While still warm, apply a light coat of Bush Telly Care Wax, wipe away any excess, and store in a dry place.

*Tip: Thin coats produce the best seasoning. A light, even coating creates a stronger, longer-lasting finish than applying too much wax.*